


LUBE OIL SYSTEM



- Note :
1. Pressure and temperature indicators are not shown
 2. Insulation, bypass and block valves for PCV, pumps and accumulator are not shown
 3. Drain pipes are not shown
 4. Individual bearing temperature indicator, alarm and trip are not shown